


Firmware Update Leica DISTO™ X3, X4, D5 & X6


To ensure that your DISTO™ device remains up to date with the latest features and improvements, it is important to perform firmware updates regularly. Firmware updates provide enhancements, new functionalities, and essential fixes that improve the device's performance and reliability. We recommend checking for firmware updates periodically to ensure your device operates at its best.

Firmware Update Instructions

1. Download the Leica DISTO Plan App from Play Store (Android) or App Store (iOS).
2. Open the app, tap the menu (top left), and select My Devices. Enable Bluetooth on both DISTO™ and mobile/tablet. Select your DISTO™ in the app, tap the "Add" or the plus "+" button, and connect. Ensure the DISTO™ is sufficiently charged (>60%).



3. Once connected, the app will prompt you for a firmware update. If not, tap the "Info" button under the device picture and select "Check for updates". If your device already has the latest software, a dialog window will appear with the message "No update available".



4. The update may take up to 30 minutes, so please ensure your phone or tablet is adequately charged.
5. After the update is complete, the DISTO™ will restart. To check the firmware version, go to Settings > Information on your DISTO™. The serial number and current firmware version will be displayed there.