DISTO™ Plan App

Measure 3D

PART OF HEXAGON

- when it has to be right

Leica Geosystems

Measure 3D
Overview





- **Point-to-Point** technology for visualization of 3D measurements directly on site
- Compatible with **DISTO™ S910** (Wi-Fi) and **DISTO™ X3/X4** (Bluetooth) on DST 360
- Features:
  - 3D real time measurements
  - Export in PDF and CAD format

- when it has to be right
Leica Geosystems

Measure 3D
Compatibility

Measure 3D is compatible with:

DISTO™ X3

or

DISTO™ X4

+

Leica DST 360

DISTO™ S910
(via Wi-Fi)

- when it has to be right

Leica Geosystems

Measure 3D
How to start



Connect with your DISTO™:

Open **My Devices** menu from side bar



Find your DISTO™ on the list and **Connect**



Remember:
Connect with DISTO™ S910 via Wi-Fi

If you need more information about connectivity, please see:

- Our **How to connect** training materials
- Our **How to connect** videos

- when it has to be **right**

Leica Geosystems

Measure 3D

How to start



Connect the DISTO™ to the **Leica DST 360** adapter:

Level the instrument before starting measuring:



- when it has to be **right**

Leica Geosystems



Measure 3D

How to measure

Select **Point**, **Line** or **Area** before you start your measurements



Remember:
The type of the measuring object can be changed anytime

Use the **ON/DIST** button to trigger measurements



Remember:
You can also measure using **ON/DIST** button on your DISTO™

Click on object button again to finish measurements



Remember:
Measure close to an existing point to snap

If you need more information, please see our
How to use Measure 3D video

- when it has to be **right**

Leica Geosystems

Measure 3D
Area calculation and coordinate system



Use red **ON/DIST** button on your DISTO™ to trigger the measurement



To determine the total area, measure each surface **separately** and then combine the measurements



First 2 points will **define the x-axis** of the measured object

- when it has to be **right**
Leica Geosystems



Measure 3D

3D View

Precise 3D plans and 3D view in real time



Draw Settings

- Open Draw Settings and select labels you would like to see
  - **Distance Label**
  - **Area Label**
  - **Circumference Label**

View:
You can easily zoom and rotate the view in different directions

Universal Solution:
The result of 3D measurement can be easily processed in CAD and also used for 2D floor plan or facade

- when it has to be **right**

Leica Geosystems

Measure 3D
Export

Export your plan in multiple formats:

- **PDF Pro**







In PDF Pro file you can find all details about measured features

- when it has to be **right**

Leica Geosystems

Measure 3D
Export

Export your plan in multiple formats:

- PDF Pro
- **3D DXF**
- **3D DWG**







- when it has to be **right**

Leica Geosystems

DISTO™ Plan App

Measure 3D

PART OF HEXAGON

- when it has to be right

Leica Geosystems